FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
/ HOME MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
FUNCTION
A – B
DISPLAY
CD / SACD
CONTINUED
SUBTITLE
UP
DOWN
LEFT
RIGHT
ENTER
/ RETURN
HDMI
YOUTUBE
MIRACAST
TOP MENU
RED / PROGRAM
GREEN / BOOKMARK
YELLOW / ZOOM
BLUE / INDEX

AUDIO
POPUP MENU
SKIP NEXT
SKIP PREV.
/ REPLAY
/ SHORT SKIP
REPEAT
OPEN / CLOSE
STOP
REW
PLAY / PAUSE
FWD
VIDEO P.

STANDBY / ON, POWER, / HOME MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION, / AV, DISPLAY, CD / SACD, CONTINUED, SUBTITLE, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, HDMI, SLEEP, YOUTUBE, TV/DTV, MIRACAST, EPG, TOP MENU, FAV, ROJO / PROGRAM, ROJO, VERDE / BOOKMARK, VERDE, AMARILLO / ZOOM, AMARILLO, AZUL / INDEX, AZUL, AUDIO, MUTE, POPARRIBA MENU, SKIP NEXT, SKIP PREV, / REPLAY, / SHORT SKIP, REPEAT, OPEN, / CLOSE, STOP, REW, PLAY / PAUSE, FWD, VIDEO P, .