FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

DV
POWER
AUDIO
DISC MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
DVD
SEARCH
DISPLAY
ZOOM
SETUP
SUBTITLE
A – B
REPEAT
UP
DOWN
LEFT
RIGHT
OK / ENTER / SELECT
RETURN
RANDOM
ANGLE
TITLE

PROGRAM
MARKER
OPEN / CLOSE
PAUSE / STEP
STOP
BACKWARD / SKIP PR.
PLAY
FORWARD / SKIP NEX.

VC
POWER
AUDIO
CLEAR
1/2/3/4/5
6/7/8/9/0
AV
VHS
CLK. / CNT.
C. LOCK
i
SEARCH
LP
ez. REPLAY / REPEAT
DOWN
UP

LEFT	
RIGHT	
OK / ENTER / SELECT	
CM SKIP	
TV / VCR	S
OUTPUT SELECT	
EJECT	
PAUSE / STEP	
STOP	
REC / ITR.	
BACKWARD / SKIP PR.	
PLAY	S
FORWARD / SKIP NEX.	

DVD, POWER, AUDIO, MUTE, DISC MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DVD, / SOURCE, SEARCH, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, REPEAT, ABAJO, IZQUIERDA, DERECHA, OK / ENTER / SELECT, RETURN, BACK, RANDOM, SLEEP, ANGLE, TV/DTV, TITLE, INFO, PROGRAM, EPG, MARKER, FAV, OPEN / CLOSE, / NET TV, PAUSE / STEP, STOP, / SMART, BACKWARD, / SKIP PR, VERDE, PLAY, AMARILLO, FORWARD, / SKIP NEX, AZUL, VCR, 1/2/3/4/5, 0 6/7/8/9/, 0AV, VHS, CLK / CNT, C LOCK, REPLAY / REPEAT, CM SKIP, TV / VCR, TV/DTV, OUTPUT SELECT, EJECT, REC / ITR, ROJO, BACKWARD / SKIP PR, FORWARD / SKIP NEX, .