FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
SOURCE
EDIT
/ ANGLE
GOTO
SETUP
/ SUBTITLE
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
↵
/ RETURN
SLOW
DVD/REC
INFO

PROGRAM
QUALITY
EJECT
▶I◀ / PAUSE
STOP
RECORD
F.BWD
PLAY
F.FWD
/ AUDIO
TV SYS
PBC
ZOOM
CM SKIP
CHANNEL+
CHANNEL -
REPEAT 1/ALL
TITLE
REPEAT A – B

POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, EDIT, / ANGLE, GOTO, SETARRIBA, / SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, / RETURN, BACK, SLOW, SLEEP, DVD/REC, TV/DTV, INFO, PROGRAM, EPG, QUALITY, FAV, EJECT, / NET TV, / PAUSE, STOP, / SMART, RECORD, ROJO, FBWD, VERDE, PLAY, AMARILLO, FFWD, AZUL, / AUDIO, TV SYS, PBC, ZOOM, CM SKIP, CHANNEL+, CHANNEL, REPEAT 1/ALL, TITLE, REPEAT A, .