FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
MUTE
/ MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
INPUT SEL.
DISC MENU
EZ VIEW
F. ADV / STEP
SPEED
SUBTITLE
TRK+
TRK -
PROG+
PROG -
UP
DOWN
LEFT
RIGHT
/ OK
/ RETURN
TIMER
TV / VCR
INFO

ANGLE / IPC
MARK SEARCH
OPEN / CLOSE
STOP
REC
REW / SKIP NEXT
PLAY / PAUSE
FWD / SKIP PREV.
DVD
VCR
MODE / REPEAT

STANDBY / ON, POWER, MUTE, / MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SEL, / AV, DISC MENU, EZ VIEW, F ADV / STEP, SPEED, SUBTITLE, TRK+, VOL+, TRK, VOL, PROG+, PROG, ABAJO, IZQUIERDA, DERECHA, / OK, / RETURN, BACK, TIMER, SLEEP, TV / VCR, TV/DTV, INFO, ANGLE / IPC, EPG, MARK SEARCH, FAV, OPEN / CLOSE, STOP, REC, ROJO, REW / SKIP NEXT, VERDE, PLAY / PAUSE, AMARILLO, FWD / SKIP PREV, AZUL, DVD, VCR, MODE / REPEAT, .