FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
XBASS
PTY / CLEAR
1/2/3/4/5
6/7/8/9/0
RANDOM
DISPLAY
TIMER SET
TIMER ON/OFF
BACKLIGHT / CONTRAST
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
MEMORY / REPEAT
SLEEP
STEREO / MONO
FILE SEARCH
P. MODE

SOUND
STOP
FOLDER DOWN
PLAY / PAUSE
FOLDER UP
AUX
USB / SD / CD
D. AUDIO
TUNER / BAND

POWER, MUTE, XBASS, MENU, PTY / CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0RANDOM, DISPLAY, TIMER SET, TIMER ON/OFF, BACKLIGHT / CONTRAST, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, MEMORY / REPEAT, BACK, SLEEP, STEREO / MONO, TV/DTV, FILE SEARCH, INFO, P MODE, EPG, SOUND, FAV, STOP, FOLDER ABAJO, VERDE, PLAY / PAUSE, AMARILLO, FOLDER ARRIBA, AZUL, AUX, USB / SD / CD, D AUDIO, TUNER / BAND, .