FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
/ AUDIO
DISC MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
AV
RANDOM
DISPLAY
ZOOM
SETUP
/ SUBTITLE
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
/ RETURN
/ ANGLE
TITLE
PROGRAM
MARKER
OPEN / CLOSE

PAUSE / STEP
STOP
BACKWARD
PLAY
FORWARD
SEARCH
DVD
VCR
REPEAT
A – B
T
POWER
MUTE
AV
VOL+
VOL-
PR+
PR-

POWER, / AUDIO, MUTE, DISC MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV, / AV, RANDOM, DISPLAY, ZOOM, SETARRIBA, / SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, / ANGLE, TV/DTV, TITLE, INFO, PROGRAM, EPG, MARKER, FAV, OPEN / CLOSE, PAUSE / STEP, STOP, BACKWARD, VERDE, PLAY, AMARILLO, FORWARD, AZUL, SEARCH, DVD, VCR, REPEAT, SLEEP, / AV, VOL+, VOL+, VOL, VOL, PR+, .