FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / STAND – BY
MUTE
iPod MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
USB PLAY/PAUSE
+10
DISPLAY
CLOCK / TIMER
BASS / TREBLE
FOLDER
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP / PRESET+
DOWN / PRESET -
LEFT
RIGHT
ENTER
USB STOP
SLEEP
DEMO
DIMMER

MEMORY
PLAY MODE
OPEN/CLOSE
iPod PLAY/PAUSE
CD STOP
REW
CD PLAY/PAUSE
FWD
X – BASS
AUDIO IN
CD / USB
iPod
TUNER
TUNING+
TUNING -

ON / STAND, POWER, MUTE, iPod MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0USB PLAY/PAUSE, / SOURCE, DISPLAY, CLOCK / TIMER, BASS / TREBLE, FOLDER, VOL+, VOL, SKIP NEXT, SKIP PREV, ARRIBA / PRESET+, ABAJO / PRESET, ABAJO, IZQUIERDA, DERECHA, ENTER, USB STOP, BACK, SLEEP, DEMO, TV/DTV, DIMMER, INFO, MEMORY, EPG, PLAY MODE, FAV, OPEN/CLOSE, / NET TV, iPod PLAY/PAUSE, CD STOP, / SMART, REW, VERDE, CD PLAY/PAUSE, AMARILLO, FWD, AZUL, BASS, AUDIO IN, CD / USB, iPod, TUNER, TUNING+, TUNING, .