FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON/STANBY
MUTE
MENU / SET
CLEAR / DEL
1/2/3/4/5
6/7/8/9/0
SOURCE
+10
TIME/DISPLAY
RANDOM
FOLDER MODE
REMOTE/BROWSE
VOLUME+
VOLUME -
SKIP NEXT / CH+
SKIP PREV / CH -
UP
DOWN
LEFT
RIGHT
ENTER/MEMO
REPEAT
SLEEP
TUNER
DIMMER

PROG/DIRECT
CLOCK
STOP
REW/TUN -
CD PLAY/PAUSE
FWD/TUN+
USB PLAY/PAUSE
IPOD PLAY/PAUSE
DAB/RDS
SDB/TONE

ON/STANBY, POWER, MUTE, MENU / SET, MENU, CLEAR / DEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, SOURCE, TIME/DISPLAY, RANDOM, FOLDER MODE, REMOTE/BROWSE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT / CH+, SKIP PREV / CH, ABAJO, IZQUIERDA, DERECHA, ENTER/MEMO, REPEAT, BACK, SLEEP, TUNER, TV/DTV, DIMMER, INFO, PROG/DIRECT, EPG, CLOCK, FAV, STOP, / SMART, REW/TUN, VERDE, CD PLAY/PAUSE, AMARILLO, FWD/TUN, AZUL, USB PLAY/PAUSE, IPOD PLAY/PAUSE, DAB/RDS, SDB/TONE, .