FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
AUDIO
MENU / LIST
CLEAR
1/2/3/4/5
6/7/8/9/0
INPUT SELECT
HDMI
DISPLAY
1.3X / 0.8X PLAY
SETUP
PROG. UP
PROG. DOWN
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
TIME SHIFT
SAT. LINK
TOP MENU
SYSTEM
SEARCH
TIMER PROG.

DVD
HDD
VCR
SUBTITLE
SKIP NEXT
SKIP PREV.
VARIABLE REPLAY
VARIABLE SKIP
REC SPEED
DUBBING
EJECT / OPEN/CLOSE
PAUSE
STOP
REC
REW
PLAY
FWD

STANDBY / ON, POWER, AUDIO, MUTE, MENU / LIST, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECT, / AV, HDMI, DISPLAY, 13X / 08X PLAY, SETARRIBA, PROG ARRIBA, PROG ABAJO, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, TIME SHIFT, SLEEP, SAT LINK, TV/DTV, TOP MENU, FAV, SYSTEM, AMARILLO, SEARCH, AZUL, TIMER PROG, DVD, HDD, VCR, SUBTITLE, SKIP NEXT, SKIP PREV, VARIABLE REPLAY, VARIABLE SKIP, REC SPEED, DUBBING, EJECT / OPEN/CLOSE, PAUSE, STOP, REC, ROJO, REW, VERDE, PLAY, FWD, .