FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTING
MENU / PLAY LIST
CANCEL
1/2/3/4/5
6/7/8/9/0
FUNCTIONS
-/-- / >10
ONE TOUCH PLAY
START
SETUP
PL II
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
RETURN
SLEEP / FL DISPLAY
SOUND / W.S.
SUB. LEV. / CH SELECT

TOP MENU / DIR. NAV.
PAUSE
STOP
SLOW/SEARCH REW
PLAY
SLOW/SEARCH FWD
DVD
iPod / USB
FM / EXT – IN
REPEAT / PLAY MODE
T
TV POWER
TV / AV
VOL+
VOL -

POWER, MUTING, MUTE, MENU / PLAY LIST, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTIONS, / SOURCE, / x, ONE TOUCH PLAY, START, SETARRIBA, PL II, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, SLEEP / FL DISPLAY, SLEEP, SOUND / WS, TV/DTV, SUB LEV / CH SELECT, EPG, TOP MENU / DIR NAV, FAV, PAUSE, STOP, SLOW/SEARCH REW, VERDE, PLAY, AMARILLO, SLOW/SEARCH FWD, AZUL, DVD, iPod / USB, FM / EXT, REPEAT / PLAY MODE, TV POWER, TV / AV, / SOURCE, VOL+, VOL, .