

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
QUICKSTART
PICTURE
EVENT LIST / TIMER
SOUND
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
↶ / REPEAT
SLEEP / RECALL
RADIO
INFO

EPG / POP MENU
HELP
FREE VIEW
RED
GREEN
YELLOW
BLUE
DVD
USB
SUBTITLE
SKIP NEXT
SKIP PREV
STEP
⏏ / EJECT
STOP
REC / OSD
REW
PLAY / PVR LIST
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, QUICKSTART, PICTURE, EVENT LIST / TIMER, SOUND, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / REPEAT, BACK, SLEEP / RECALL, SLEEP, RADIO, TV/DTV, INFO, EPG / POP MENU, EPG, HELP, FAV, FREE VIEW, / NET TV, ROJO, VERDE, AMARILLO, AZUL, DVD, USB, SUBTITLE, SKIP NEXT, SKIP PREV, STEP, / EJECT, STOP, REC / OSD, REW, PLAY / PVR LIST, FWD, .