

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
CH. LIST
DISPLAY
HOLD
ASPECT
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
↻ / RECALL
SLEEP
TV / RADIO
INDEX

🖱 / MOUSE
FAV
🏠 / HOME
e / IE
RED
GREEN
YELLOW
BLUE
AUDIO
REVEAL
SIZE
SUBPAGE
SUBTITLE
SKIP NEXT
SKIP PREV
PIC. MODE
S.MODE
PAUSE
STOP
REW
PLAY
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, CH LIST, DISPLAY, HOLD, ASPECT, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / RECALL, BACK, SLEEP, TV / RADIO, TV/DTV, INDEX, INFO, / MOUSE, EPG, FAV, / HOME, / NET TV, / IE, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, REVEAL, SIZE, SUBPAGE, SUBTITLE, SKIP NEXT, SKIP PREV, PIC MODE, S.MODE, PAUSE, STOP, REW, PLAY, FWD, .