

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.



| |
|---------------------|
| POWER |
| MUTING -20dB |
| CANCEL |
| 1/2/3/4/5 |
| 6/7/8/9/0 |
| >10 |
| PRO LOGIC |
| AUTO / MONO |
| TEST |
| VOLUME+ |
| VOLUME - |
| SKIP NEXT |
| SKIP PREV |
| BALANCE L |
| BALANCE R |
| REPEAT |
| SLEEP |
| TUNER / BAND |
| PROGRAM |
| DELAY TIME |
| OPEN / CLOSE |
| PAUSE |
| STOP |
| PLAY |
| VCR |

| |
|--------------------------|
| VDP |
| PHONO |
| CD |
| CENTER+ |
| CENTER - |
| SURROUND - |
| SURROUND+ |
| TAPE PLAY REVERSE |
| DECK 1 / 2 |
| TAPE OPEN/CLOSE |
| TAPE STOP |
| TAPE REC PAUSE |
| TAPE REW |
| TAPE PLAY |
| TAPE FWD |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

POWER, MUTING, 20dB, MUTE, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, PRO LOGIC, AUTO / MONO, TEST, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, BALANCE L, IZQUIERDA, BALANCE R, DERECHA, REPEAT, BACK, SLEEP, TUNER / BAND, TV/DTV, PROGRAM, EPG, DELAY TIME, FAV, OPEN / CLOSE, / NET TV, PAUSE, STOP, / SMART, PLAY, AMARILLO, VCR, VDP, PHONO, CENTER+, CENTER, ABAJO, SURROUND, SURROUND+, TAPE PLAY REVERSE, DECK 1 / 2, TAPE, OPEN/CLOSE, TAPE STOP, TAPE REC PAUSE, ROJO, TAPE REW, VERDE, TAPE PLAY, TAPE FWD, AZUL, .