

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
/ HOME
DISPLAY
SIZE/ASPECT
MIX
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
SLEEP
TV/RADIO
INDEX/REC LIST

CH. LIST
FAV
BROWSER
/ MOUSE
HOLD
RED
GREEN
YELLOW
BLUE
I/II / AUDIO
REVEAL
P.MODE
S.MODE
SUBTITLE
SKIP NEXT
SKIP PREV
T.SHIFT
STOP
REW
PLAY/PAUSE
FWD

STANDBY, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, / HOME, DISPLAY, SIZE/ASPECT, MIX, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, TV/RADIO, TV/DTV, INDEX/REC LIST, INFO, CH LIST, EPG, FAV, BROWSER, / NET TV, / MOUSE, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, I/II / AUDIO, REVEAL, PMODE, SMODE, SUBTITLE, SKIP NEXT, SKIP PREV, TSHIFT, STOP, REW, PLAY/PAUSE, FWD, .