

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
-/--
DISPLAY
ASPECT
S.PAGE
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
ENTER
SLEEP
R.LIST
INDEX

EPG
FAV
AUTO
HOLD
RED
GREEN
YELLOW
BLUE
AUDIO
MEDIA
REVEAL
SIZE
P.MODE
S.TITLE
FAV+
FAV -
SKIP NEXT
SKIP PREV
RADIO
S.MODE
STOP
RECORD
REW
PLAY/PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, DISPLAY, ASPECT, SPAGE, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, RLIST, TV/DTV, INDEX, INFO, EPG, FAV, AUTO, / NET TV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, MEDIA, REVEAL, SIZE, P.MODE, STITLE, FAV+, VOL+, FAV, VOL, SKIP NEXT, SKIP PREV, RADIO, S.MODE, STOP, RECORD, REW, PLAY/PAUSE, FWD, .