

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER ON
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
CLEAR
RDS
A. PRESET
P. SCAN
STEREO
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
PREV - CH
SLEEP
HARMAN VOLUME
DIM
MEM

DIRECT
PAUSE
STOP
REW
PLAY
FWD
POWER OFF
TONE CONTROL
AM/FM
AUX
BLUETOOTH
DIGITAL
NETWORK
PHONO
USB
V.TUNER
CH/TUNE+
CH/TUN -
SPEAKER 1
SPEAKER 2

ORIGINAL, SARRIBAERIOR, POWER ON, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0CLEAR, RDS, A PRESET, P SCAN, STEREO, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, PREV, BACK, SLEEP, HARMAN VOLUME, TV/DTV, DIM, INFO, MEM, EPG, DIRECT, FAV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, POWER OFF, TONE CONTROL, AM/FM, AUX, AZULTOOTH, DIGITAL, NETWORK, PHONO, USB, VTUNER, CH/TUNE+, CH/TUN, SPEAKER 1, SPEAKER 2, Keys Functions LAYOUT, Code, 689, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .