

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



MUTE
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
.
HOME
DISPLAY
SETUP
SUBTITLE
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
STEP
SHUFFLE
TITLE

ANGLE
L/R
EJECT
STOP
REW
PLAY/PAUSE
FWD
AUDIO OUT
SEARCH
DVD
MEMORY CARD
MUSIC
ONLINE MEDIA
PHOTO
VIDEO
ROTATE
PS/IS
LANGUAGE
PAGE+
PAGE -
REPEAT
SLOW
VIDEO OUT
L/R

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SOURCE, HOME, DISPLAY, SETARRIBA, SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, STEP, SLEEP, SHUFFLE, TV/DTV, TITLE, INFO, ANGLE, EPG, L/R, FAV, EJECT, / NET TV, STOP, / SMART, REW, VERDE, PLAY/PAUSE, AMARILLO, FWD, AZUL, AUDIO OUT, SEARCH, DVD, MEMORY CARD, MUSIC, ONLINE MEDIA, PHOTO, VIDEO, ROTATE, PS/IS, LANGUAGE, PAGE+, PAGE, REPEAT, SLOW, VIDEO OUT, Keys Functions LAYOUT, Code, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .