FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando. El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto. Revise que localiza todas las funciones que necesita antes de realizar la compra.



1	V BOX POWER
	□⊠
	MENU
	EXIT
	1/2/3/4/5
	6/7/8/9/0
	USB
	RADIO
	PVR
	STALKER
	мзи.ту
	VOL+
	VOL -
	CH+
	CH -
	UP
	DOWN
	LEFT
	RIGHT
	OK
	RECALL
	TIMER
	WEB TV
	INFO
	EPG

	RED/ U TUBE
(GREEN/SUB - T
YI	ELLOW/FORMAT
	BLUE/TTX
	AUDIO
	SKIP NEXT
	SKIP PREV
	STOP
	REC
	REW
	PLAY/PAUSE
	FWD

ORIGINAL, SARRIBAERIOR, TV BOX POWER, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0USB, / SOURCE, RADIO, PVR, STALKER, M3UTV, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, RECALL, BACK, TIMER, SLEEP, WEB TV, TV/DTV, INFO, EPG, ROJO/ U TUBE, ROJO, VERDE/SUB, VERDE, AMARILLO/FORMAT, AMARILLO, AZUL/TTX, AZUL, AUDIO, SKIP NEXT, SKIP PREV, STOP, REC, REW, PLAY/PAUSE, FWD, Keys Functions LAYOUT, Code, 693, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .