

# FUNCIÓNES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.  
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.  
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



OFF/ON
MUTING -20db
MODE
V.BASS
1/2/3/4/5
6/7/8/9/0
>10
VOLUME+
VOLUME -
CD SKIP NEXT
CD SKIP PREV
CANCEL
SLEEP
CD
ON/FLEAT
PROGRAM
TUNER/BAND
CD PAUSE
CD STOP
CD PLAY
EASY PLAY CD
EASY PLAY/TAOE
EASY PLAY TUNER
TAPE REV PLAY
DECK 1 - 2

TAPE PAUSE
TAE PLAY
TAPE REW
TAPE PLAY
TAPE REW

ORIGINAL, SARRIBAERIOR, OFF/ON, POWER, MUTING, 20db, MUTE, MODE, MENU, VBASS, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, VOLUME+, VOL+, VOLUME, VOL, CD SKIP NEXT, CD SKIP PREV, CANCEL, BACK, SLEEP, TV/DTV, ON/FLEAT, INFO, PROGRAM, EPG, TUNER/BAND, FAV, CD PAUSE, CD STOP, / SMART, CD PLAY, AMARILLO, EASY PLAY CD, EASY PLAY/TAOE, EASY PLAY TUNER, TAPE REV PLAY, DECK 1, TAPE PAUSE, TAE PLAY, TAPE REW, VERDE, TAPE PLAY, AZUL, Keys Functions LAYOUT, Code, 693, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .