


FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
FADE MUTING
MENU/PL
CANCEL
1/2/3/4/5
6/7/8/9/0
10
>10
DISP/CHARA
BASS/TREBLE
SET UP
SUBTITLE
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP/PTY+
DOWN/PTY -
LEFT/PTY SEARCH
RIGHT/TA/NEWS/INFO
ENTER/SET
RETURN
SLEEP/A.STBY
S.TURBO II
CLOCK/TIMER

DIMMER/ECO
SCAN MODE
STOP
REW
FWD
AUDIO/MPX
TOP MENU/PG
AUDIO IN/TV
DVD/CD
TUNER
USB
C.VOICE
REPEAT

ORIGINAL, SARRIBAERIOR, POWER, FADE MUTING, MUTE, MENU/PL, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SOURCE, DISP/CHARA, BASS/TREBLE, SET ARRIBA, SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP PREV, /PTY+, ABAJO, /PTY, IZQUIERDA, /PTY SEARCH, DERECHA, /TA/NEWS/INFO, ENTER/SET, RETURN, BACK, SLEEP/ASTBY, SLEEP, STURBO II, TV/DTV, CLOCK/TIMER, INFO, DIMMER/ECO, EPG, SCAN MODE, FAV, STOP, / SMART, REW, VERDE, FWD, AZUL, AUDIO/MPX, TOP MENU/PG, AUDIO IN/TV, DVD/CD, TUNER, USB, CVOICE, REPEAT, BLACK, Keys Functions LAYOUT, Code, 695, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .