

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.



CD POWER
MUTE
OPTION
CLEAR
1/2/3/4/5
6/7/8/9/0
INPUT
+10
QUEUE
DIMMER
SETUP
ⓧ / RANDOM
VOLUME +
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
BACK
INFO
SOURCE DIRECT
STOP

PLAY/PAUSE
AMP POWER
AUX
RECORDER
OPT/COAX
CD
PHONO
♻️ / REPEAT

ORIGINAL, SARRIBAERIOR, CD POWER, POWER, MUTE, OPTION, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, QUEUE, DIMMER, SETARRIBA, / RANDOM, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, INFO, SOURCE DIRECT, EPG, STOP, / SMART, PLAY/PAUSE, AMARILLO, AMP POWER, AUX, RECORDER, OPT/COAX, PHONO, / REPEAT, Keys Functions LAYOUT, Code, 697, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .