

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
USB
MODE
DISPLAY
FIND
OPT
TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
RECALL
SLEEP
TV/R
INFO

EPG
FAV
RED / AUDIO
GREEN / PAUSE
YELLOW / ZOOM
BLUE / SAT
F1
SUB
SKIP NEXT
SKIP PREV
PAGE+
PAGE -
TIME
PAUSE
STOP
REC
REWE
PLAY
FWDD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0USB, / SOURCE, MODE, DISPLAY, FIND, OPT, TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, RECALL, BACK, SLEEP, TV/R, TV/DTV, INFO, EPG, FAV, ROJO, / AUDIO, VERDE, / PAUSE, AMARILLO, / ZOOM, AZUL, / SAT, SUB, SKIP NEXT, SKIP PREV, PAGE+, PAGE, TIME, PAUSE, STOP, REC, REWE, PLAY, FWDD, SHFIT+AZUL, Keys Functions LAYOUT, Code, 698, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .