

# FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
USB
LIST
FIND
GOTO
MODE
TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
RECALL
SLEEP
TV/R
INFO

EPG
FAV
RED
GREEN
YELLOW
BLUE
TIMER
AUDIO
SUB
SKIP NEXT
SKIP RPEV
PAGE+
PAGE -
PAUSE
STOP
REC
REW
PLAY
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0USB, / SOURCE, LIST, FIND, GOTO, MODE, TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, RECALL, BACK, SLEEP, TV/R, TV/DTV, INFO, EPG, FAV, ROJO, VERDE, AMARILLO, AZUL, TIMER, AUDIO, SUB, SKIP NEXT, SKIP RPEV, PAGE+, PAGE, PAUSE, STOP, REC, REW, PLAY, FWD, Keys Functions LAYOUT, Code, 698, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .