

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
CH LIST
ZOOM
S.MODE
P.MODE
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
ENTER
FAV+
FAV LIST
FREEZE

RED
GREEN
YELLOW
BLUE
SKIP NEXT
SKIP RPEV
REPEAT
A - B
STOP
REW
PLAY/PAUSE
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, CH LIST, ZOOM, SMODE, PMODE, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, FAV+, INFO, FAV LIST, FAV, FREEZE, / SMART, ROJO, VERDE, AMARILLO, AZUL, SKIP NEXT, SKIP RPEV, REPEAT, SIFT+BACK, STOP, REW, PLAY/PAUSE, SIFT+AMARILLO, FWD, Keys Functions LAYOUT, Code, 7046, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR, ELECTRONICSCOM, .