

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
DISC MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
[] / FUNCTION
TITLE/POPUP
[] / HOME
SOUND EFFECT
SPEAKER LEVEL
SUBTITLE
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP/PRESET+
DOWN/PRESET -
LEFT/TUNING -
RIGHT/TUNING+
ENTER
[] / REPEAT
SLEEP
INFO/MENU
OPEN/CLOSE

PAUSE/STEP
STOP
REC
REW
PLAY
FWD
AUDIO
RED
GREEN
YELLOW
BLUE / MONO/STEREO

ORIGINAL, SARRIBAERIOR, POWER, MUTE, DISC MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, / FUNCTION, / SOURCE, TITLE/POPARRIBA, / HOME, SOUND EFFECT, SPEAKER LEVEL, SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP PREV, /PRESET+, ABAJO, /PRESET, IZQUIERDA, /TUNING, DERECHA, /TUNING+, ENTER, / REPEAT, BACK, SLEEP, INFO/MENU, INFO, OPEN/CLOSE, NET, PAUSE/STEP, SMART, TUBE, STOP, VIDEO, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, AZUL / MONO/STEREO, Keys Functions LAYOUT, Code, 733, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWW.SARRIBAERIOR.ELECTRONICSCOM, .