

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
TV MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
CH. LIST
INDEX
HOLD
MIX
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
RECALL
SLEEP
PIC.
INFO

EPG
FAV
ASPECT
FREEZE
RED
GREEN
YELLOW
BLUE
AUDIO
LIST
REVEAL
SIZE
SUBTITLE
SUBPAGE
SKIP NEXT
SKIP PREV
TV / RADIO
SOUND
PAUSE
STOP
REC / REP.
REW
PLAY
FWD

POWER, MUTE, TV MENU, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, CH LIST, INDEX, HOLD, MIX, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, RECALL, BACK, SLEEP, PIC, TV/DTV, INFO, EPG, FAV, ASPECT, / NET TV, FREEZE, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, LIST, REVEAL, SIZE, SUBTITLE, SUBPAGE, SKIP NEXT, SKIP PREV, TV / RADIO, TV/TDV, SOUND, PAUSE, STOP, REC / REP, REW, PLAY, FWD, .