

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
TV / RADIO
PR. LIST
ZOOM
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
↻ / RECALL
SLEEP
ATV / DTV
INFO
INDEX

FAV
PIC. MODE
RED
GREEN
YELLOW
BLUE
S. MODE
I/II / AUDIO
REVEAL
REC LIST
SUBTITLE
SKIP NEXT
SKIP PREV
PAUSE / SUBPAGE
STOP / HOLD
REC
REW
PLAY / SIZE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, SOURCE, TV / RADIO, PR LIST, ZOOM, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / RECALL, BACK, SLEEP, ATV / DTV, TV/DTV, INFO, INDEX, EPG, FAV, PIC MODE, / NET TV, ROJO, VERDE, AMARILLO, AZUL, S MODE, I/II / AUDIO, REVEAL, REC LIST, SUBTITLE, SKIP NEXT, SKIP PREV, PAUSE / SUBPAGE, STOP / HOLD, REC, REW, PLAY / SIZE, FWD, .