

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER	BLUE / FILE
MUTE	AUDIO
MENU	SETUP
EXIT	HOME
1/2/3/4/5	SLIDE SHOW
6/7/8/9/0	ASPECT
OUTPUT	ROTATE
GO TO	PAGE DOWN
VIEW	PAGE UP
ZOOM	SKIP PREV.
TITLE	SKIP NEXT
SUBTITLE	PAUSE
VOL+	STOP
VOL-	REW
UP	PLAY
DOWN	FWD
LEFT	OSD
RIGHT	SORT
OK	
BACK	
STORAGE	
FOLDER	
RED / FILM	
GREEN / PHOTO	
YELLOW / MUSIC	

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0OUTPUT, GO TO, VIEW, ZOOM, TITLE, SUBTITLE, VOL+, VOL-, ABAJO, IZQUIERDA, DERECHA, BACK, STORAGE, INFO, FOLDER, FAV, ROJO / FILM, ROJO, VERDE /, PHOTO, VERDE, AMARILLO / MUSIC, AMARILLO, AZUL / FILE, AZUL, AUDIO, SETARRIBA, HOME, SLIDE SHOW, ASPECT, ROTATE, PAGE ABAJO, PAGE ARRIBA, SKIP PREV, SKIP NEXT, PAUSE, STOP, REW, PLAY, FWD, OSD, EPG, SORT, .