

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
AUDIO
MENU/LIST
CLEAR
1/2/3/4/5
6/7/8/9/0
AV/INPUT
TIMESHIFT
DISPLAY
ZOOM
PIP
SUBTITLE
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
TIMER REC
TV/DVD
CHP. ADD
HOME
DUBBING

OPEN/CLOSE
PAUSE/STEP
STOP
REC
REW
PLAY
FWD
SETUP
DVD
HDD
THUMBNAIL
SEARCH
TITLE
INSTANT SKIP
REPEAT
A-B
MARKER
REC MODE
T
POWER
MUTE
AV/INPUT
CH -/+
VOL -/+

POWER, AUDIO, MUTE, MENU/LIST, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV/INPUT, TIMESHIFT, DISPLAY, ZOOM, PIP, SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, TIMER, REC, SLEEP, TV/DVD, TV/DTV, CHP, ADD, INFO, HOME, EPG, DUBBING, FAV, OPEN/CLOSE, PAUSE/STEP, STOP, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SETARRIBA, DVD, HDD, THUMBNAIL, SEARCH, TITLE, INSTANT SKIP, REPEAT, MARKER, MODE, AV/INPUT, VOL, .