FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando. El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto. Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
-/
DISPLAY
ASPECT
SUBTITLE
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
ок
¢,
SLEEP
TV / RADIO
INDEX

EPG
FAV
AUTO
HOLD
RED
GREEN
YELLOW
BLUE
NICAM
P. MODE
S. MODE
MEDIA
REVEAL
SIZE
LANG
SUBPAGE
SKIP NEXT
SKIP PREV
FAV -
FAV+
STOP
REC
REW
PLAY / PAUSE
FWD

STANDBY, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, DISPLAY, ASPECT, SUBTITLE, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, TV / RADIO, TV/DTV, INDEX, INFO, EPG, FAV, AUTO, / NET TV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, NICAM, P MODE, S MODE, MEDIA, REVEAL, SIZE, LANG, SUBPAGE, SKIP NEXT, SKIP PREV, FAV, FAV+, STOP, REC, REW, PLAY / PAUSE, FWD, .