

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



MUTE
MENU
EXIT
1 / RDS DISPLAY
2
3 / TA
4 / PTY -
5 / PTY SEARCH
6 / PTY+
7/8/9/0
TV SOURCE
2D - 3D
FULL SCREEN
DSP
TOOLS
S/W LEVEL
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT

ENTER
RETURN
SLEEP
V - TUNER
INFO
HOME
3D SOUND
EJECT
PAUSE
STOP
REW
PLAY
FWD
SMART HUB
PL II
TUNING/CH+
TUNING/CH -
REPEAT
SEARCH
TITLE MENU / POP-UP
SOUND EFFECT
RED / A
GREEN / B
YELL. / C / TUN. MEM.
BLUE / D / MO/ST

POWER, MUTE, MENU, EXIT, 1 /, RDS DISPLAY, 3 / TA, 4 / PTY, 5 / PTY SEARCH, 6 / PTY+, 7/8/9/, 0TV SOURCE, / SOURCE, FULL SCREEN, DSP, TOOLS, S/W LEVEL, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, TUNER, TV/DTV, INFO, HOME, EPG, 3D SOUND, FAV, EJECT, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SMART HUB, PL II, TUNING/CH+, TUNING/CH, REPEAT, SEARCH, TITLE MENU, / POP, SOUND EFFECT, ROJO / A, ROJO, VERDE / B, YELL / C / TUN MEM, AZUL / D / MO/ST, .