

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY / ON
MUTE
MENU
FINALIZE
1/2/3/4/5
6/7/8/9/0
SOURCE
EDIT
DISPLAY
ZOOM
ANGLE
SUBTITLE
VOL+
VOL-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
SELECT
RETURN / P←→P
TIMER
TV
ADD / CLEAR

PROG.
QUALITY
OPEN / CLOSE
PAUSE / STEP
STOP
REC / OTR.
REV.
PLAY
FWD
AUDIO
DV / USB
ERASE
DISC OPER.
GO TO
SETUP
SCAN
SLOW
CHANNEL-
CHANNEL+
REPEAT
PS / IS
TITLE
NAVIGATION
RANDOM

STANDBY / ON, POWER, MUTE, MENU, FINALIZE, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / AV, EDIT, DISPLAY, ZOOM, ANGLE, SUBTITLE, VOL+, VOL-, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, SELECT, RETURN / P, BACK, TIMER, SLEEP, TV/DTV, ADD / CLEAR, INFO, PROG, EPG, QUALITY, FAV, OPEN / CLOSE, PAUSE / STEP, STOP, REC / OTR, ROJO, REV, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, DV / USB, ERASE, DISC OPER, GO TO, SETARRIBA, SCAN, SLOW, CHANNEL-, CHANNEL+, REPEAT, PS / IS, TITLE, NAVIGATION, RANDOM, .