

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
SCH LIST
DIGEST
ASPECT
PICTURE MODE
TXT
VOL+ / VOL-
P+ / P-
REC LIST
PROGRAM
UP
DOWN
LEFT
RIGHT
OK
BACK
SLEEP
DTV/USB
INFO

GUIDE
FAV
RED
GREEN
YELLOW
BLUE
AUDIO
CANCEL
TXT CANC
TXT HOLD
TXT INDEX
TXT REVEAL
TXT SIZE
TXT SUBPAGE
SCREEN
EFFECT
ZOOM
SUBTITLE
SKIP NEXT PREV CHAP
PAUSE
STOP
EJECT
REPEAT

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, INPUT, SCH LIST, DIGEST, ASPECT, PICTURE, MODE, TXT, VOL, + / VOL, VOL+ / VOL, / P, REC LIST, INFO, PROGRAM, EPG, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, DTV/USB, TV/DTV, GUIDE, FAV, ROJO, VERDE, AMARILLO, AZUL, AUDIO, CANCEL, CANC, TXT HOLD, TXT INDEX, TXT REVEAL, TXT SIZE, TXT SUBPAGE, SCREEN, EFFECT, ZOOM, SUBTITLE, SKIP NEXT PREV CHAP, P+/P-, PAUSE, STOP, EJECT, REPEAT, .