

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
LIST
DISPLAY
ASPECT
SETUP
TXT
VOL+
VOL -
CH+
CH -
LEFT / RIGHT
UP / DOWN
OK
BACK
Zzz
TV
INDEX
GUIDE
PREF

SMODE
TV/RADIO
AUTO
HOLD
RED
GREEN
YELLOW
BLUE
AUDIO
HOME
A - B
BROWSER
USB
PMODE
REVEAL
SIZE
GOTO
SUBTITLE
SKIP NEXT / PREV
REFRESH
STOP
REC
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, LIST, DISPLAY, ASPECT, SETARRIBA, TXT, VOL+, VOL, CH+, IZQUIERDA / DERECHA, ARRIBA / ABAJO, ARRIBA/ABAJO, BACK, SLEEP, TV/DTV, INDEX, INFO, GUIDE, EPG, PREF, FAV, SMODE, TV/RADIO, AUTO, HOLD, ROJO, VERDE, AMARILLO, AZUL, AUDIO, HOME, BROWSER, USB, SHIFT, + / SOURCE, PMODE, REVEAL, SIZE, GOTO, SUBTITLE, SKIP NEXT / PREV, P +/, REFRESH, STOP, REC, REW, PLAY / PAUSE, FWD, .