

# FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



SYSTEM ON
MUTE
TOP MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
∞ / SHUFFLE
SETUP
VOLUME+
VOLUME-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
CLOCK
DIMMER
FAVORITES
PAUSE / AUTO TUNE
STOP / PTY.
REW
PLAY / RDS DISP.

FWD
SYSTEM OFF
BAND
BT AUDIO
NET SERVICE
iPOD / USB
M. SERVER
NETWORK
FOLDER- / SORT
FOLDER+ / +FAV.
↻ / REPEAT

SYSTEM ON, POWER, MUTE, TOP MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SHUFFLE, SETARRIBA, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, CLOCK, SLEEP, DIMMER, INFO, FAVORITES, FAV, PAUSE / AUTO TUNE, STOP / PTY, REW, VERDE, PLAY / RDS DISP, AMARILLO, FWD, AZUL, SYSTEM OFF, BAND, BT AUDIO, NET SERVICE, IPOD, / USB, M SERVER, NETWORK, FOLDER, / SORT, FOLDER+ / +FAV, / REPEAT, .