

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
FAV -
AUTO
ASPECT
ANGLE
TTX
VOL +/-
CH +/-
UP
DOWN
LEFT
RIGHT
OK
SLEEP
TV/RADIO
INFO
EPG
FAV

FAV+
HOLD
RED / D.SETUP
GREEN / D.MENU
YELLOW / D.TITLE
BLUE / REPEAT
AUDIO
REVEAL
ZOOM
SUB - P
SUB - T
SKIP NEXT
SKIP PREV
TSR
P.MODE
INDEX
REC LIST
S.MODE
EJECT
FREEZE
STOP
REC
REW
PLAY/PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, FAV, AUTO, ASPECT, ANGLE, TTX, VOL +/, CH +/, P +/, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, TV/RADIO, TV/DTV, INFO, EPG, FAV, FAV+, / NET TV, HOLD, / SMART, ROJO / DSETARRIBA, ROJO, VERDE / DMENU, VERDE, AMARILLO / DTITLE, AMARILLO, AZUL / REPEAT, AZUL, AUDIO, REVEAL, SHFIT+, ZOOM, SUB, SKIP NEXT, SKIP PREV, TSR, P.MODE, INDEX, REC LIST, SMODE, EJECT, FREEZE, STOP, REC, REW, PLAY/PAUSE, FWD, .