FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando. El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto. Revise que localiza todas las funciones que necesita antes de realizar la compra.



O	
MUTE	_
MENU	
EXIT	
1/2/3/4/5	
6/7/8/9/0	
- / SOURC	Ε
FOCUS / A-I	į
≣? / MTS	
E ♦ / SLEEP	
PIP / REP.	
VOL+	
VOL-	
PRG.+	
PRG	
UP	
DOWN	
LEFT	
RIGHT	
≣i / TIME	
TV	
INFO	
CTRL.	
SOUND	

PICTURE	
STILL / SUBT.	
RED / DELETE	_
GREEN / SKIP	
YELLOW / INSERT	
BLUE / REPLACE	
SIZE / AUDIO	
CVBS 1	
CVBS 2	
CVBS 3	
Y.Pb.Pr.	
YC 1	
YC 2	
PC	
DVI	
I / PREPG.	
NORMAL / TITLE	
	Ì

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SOURCE, / AV, FOCUS / A, / MTS, / SLEEP, PIP / REP, VOL+, VOL, PRG+, PRG, ABAJO, IZQUIERDA, DERECHA, / TIME, SLEEP, TV/DTV, INFO, CTRL, EPG, SOUND, FAV, PICTURE, STILL, / SUBT, ROJO / DELETE, ROJO, VERDE / SKIP, VERDE, AMARILLO / INSERT, AMARILLO, AZUL / REPLACE, AZUL, SIZE / AUDIO, CVBS 1, CVBS 2, CVBS 3, YPbPr, YC 1, YC 2, DVI, / PREPG, NORMAL / TITLE, .