

# FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
🔊 / AUDIO
🏠 / HOME
CLEAR
1/2/3/4/5
6/7/8/9/0
SEARCH
DISPLAY
ZOOM
SUBTITLE - ON/OFF
📄 / SUBTITLE
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
RESOLUTION
TITLE / POP-UP
MARKER
OPEN / CLOSE
PAUSE
STOP

SCAN REW
PLAY
SCAN FWD
PIP AUDIO
DISC MENU
PIP
REPEAT
RED / A
GREEN / B
YELLOW / C
BLUE / D

POWER, / AUDIO, MUTE, / HOME, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SEARCH, DISPLAY, ZOOM, SUBTITLE, ON/OFF, / SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, RESOLUTION, TV/DTV, TITLE / POP, INFO, MARKER, FAV, OPEN / CLOSE, PAUSE, STOP, SCAN REW, VERDE, PLAY, AMARILLO, SCAN FWD, AZUL, PIP AUDIO, DISC MENU, PIP, REPEAT, ROJO / A, ROJO, VERDE / B, AMARILLO / C, AZUL / D, .