

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
PVR LIST
REVEAL
ZOOM
LANG.
TEXT
VOL -/+
CH -/+
UP
DOWN
LEFT
RIGHT
OK
RECALL
SLEEP
TV / DTV
INFO
EPG
FAV

PICTURE
STILL
HOLD
RED
GREEN
YELLOW
BLUE
I / II
SOUND
MEDIA
SIZE
SUBPAGE
SUBTITLE
SKIP NEXT
SKIP PREV
FAV -
FAV+
T.SHIFT
TV / RADIO
INDEX
STOP
REC
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, PVR LIST, REVEAL, ZOOM, LANG, TEXT, VOL, ABAJO, IZQUIERDA, DERECHA, RECALL, BACK, SLEEP, TV / DTV, TV/DTV, INFO, EPG, FAV, PICTURE, / NET TV, STILL, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, I / II, SOUND, MEDIA, SIZE, SUBPAGE, SUBTITLE, SKIP NEXT, SKIP PREV, FAV, FAV+, TSHIFT, TV / RADIO, TV/DTV, INDEX, STOP, REC, REW, PLAY / PAUSE, FWD, .