FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando. El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto. Revise que localiza todas las funciones que necesita antes de realizar la compra.



0
□ X
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
Q.MENU
номе
SIXE
MIX
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK / LIST
BACK
HOLD
INFO
GUIDE

NETFLIX YOUTUBE PRIME VIDEO RED GREEN YELLOW BLUE AUDIO / LANG / I/I CANCEL REVEAL
PRIME VIDEO RED GREEN YELLOW BLUE AUDIO / LANG / I/I
RED GREEN YELLOW BLUE AUDIO / LANG / I/I CANCEL
GREEN YELLOW BLUE AUDIO / LANG / I/I CANCEL
YELLOW BLUE AUDIO / LANG / I/I CANCEL
BLUE AUDIO / LANG / I/I CANCEL
AUDIO / LANG / I/I
CANCEL
REVEAL
SUBTITLE
SKIP NEXT
SKIP PREV
RECALL
STOP
REW
PLAY/PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, QMENU, HOME, SIXE, MIX, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, OK / LIST, BACK, HOLD, SLEEP, INFO, GUIDE, EPG, INDEX, FAV, NETFLIX, / NET TV, YOUTUBE, PRIME VIDEO, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO /, LANG / I, /II, CANCEL, REVEAL, SUBTITLE, SKIP NEXT, SKIP PREV, RECALL, STOP, REW, PLAY/PAUSE, FWD, .