FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando. El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto. Revise que localiza todas las funciones que necesita antes de realizar la compra.



	POWER
	MUTE
	OPTION
1	/2/3/4/5
6	/7/8/9/0
	SOURCE
	GUIDE
ı	DISPLAY
	СОТО
	SETUP
1	ELETEXT
	VOL+
	VOL-
S	KIP NEXT
S	KIP PREV.
	UP
	DOWN
	LEFT
	RIGHT
	ENTER
ಣ	/ RETURN
T	ME SHIFT
T	V SYSTEM
j	REC LIST
	EPG

	BROWSER	
3	PAUSE / STEP	
	STOP	
	REC	
	REW	
	PLAY	
	FWD	
	TIMER	•
	AUDIO	
	CONFIRM	
	ZOOM	
	СОРУ	
	SUBTITLE	
	CH+	
	СН-	
	SELECT	
	REPEAT	

POWER, MUTE, OPTION, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / AV, GUIDE, DISPLAY, GOTO, SETARRIBA, TELETEXT, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, TIME SHIFT, SLEEP, TV SYSTEM, TV/DTV, REC LIST, INFO, EPG, BROWSER, FAV, PAUSE / STEP, STOP, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TIMER, AUDIO, CONFIRM, ZOOM, COPY, SUBTITLE, CH+, SELECT, REPEAT, .