

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



HOME
EXIT
1/2/3/4/5
6/7/8/9/0
SOCIAL VIEW
DIGITAL / ANALOG
OPTIONS
VOL+
VOL -
/ PROG.+
/ PROG. -
UP
DOWN
LEFT
RIGHT
RETURN / BACK
DISCOVER
TV / RADIO
/ i+
GUIDE

NETFLIX
TV PAUSE
APPS / SEN
RED
GREEN
YELLOW
BLUE
AUDIO
SYNC. MENU
RELATED SEARCH
3D
i- MANUAL / ?
FOOTBALL
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, MUTE, HOME, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 0 / , / SOURCE, SOCIAL VIEW, DIGITAL / ANALOG, OPTIONS, VOL+, VOL-, / PROG+, / PROG, ABAJO, IZQUIERDA, DERECHA, RETURN / BACK, BACK, DISCOVER, SLEEP, TV / RADIO, TV/DTV, / i+, INFO, GUIDE, EPG, NETFLIX, / NET TV, TV PAUSE, APPS / SEN, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, SYNC MENU, RELATED SEARCH, MANUAL, FOOTBALL, FAV, PAUSE, STOP, REC, REW, PLAY, FWD, .