

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
/ AUDIO
/ HOME
RESOLUTION
1/2/3/4/5
6/7/8/9/0
PR. LIST
GOTO
TIME SHIFT
TEXT
VOL+
VOL-
PR.+
PR.-
UP
DOWN
LEFT
RIGHT
OK
/ BACK
TIMER REC
TV PVR
INFO
GUIDE
FAV

RED / REPEAT
GREEN / ZOOM
YELLOW / MARKER
BLUE / EDIT
/ SUBTITLE
SKIP NEXT
SKIP PREV.
PAGE UP
PAGE DOWN
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, / AUDIO, MUTE, / HOME, MENU, RESOLUTION, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0PR LIST, GOTO, TIME SHIFT, TEXT, VOL+, VOL-, PR+, ABAJO, IZQUIERDA, DERECHA, / BACK, BACK, TIMER REC, SLEEP, TV PVR, TV/DTV, INFO, GUIDE, EPG, FAV, ROJO / REPEAT, ROJO, VERDE / ZOOM, VERDE, AMARILLO / MARKER, AMARILLO, AZUL / EDIT, AZUL, / SUBTITLE, SKIP NEXT, SKIP PREV, PAGE ARRIBA, PAGE ABAJO, PAUSE, STOP, REC, REW, PLAY, FWD, .