

## FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.  
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.  
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



⏻
🔇
☰
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
CH.LIST
🏠
DEEZER
EDIT
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
↩
FREE
BROWSER
INFO

GUIDE
DISNEY+
NETFLIX
YOUTUBE
PRIME VIDEO
RED
GREEN
YELLOW
BLUE
MEDIA
SUBTITLE
PLAY/PAUSE

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, CHLIST, DEEZER, EDIT, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, FREE, SLEEP, BROWSER, TV/DTV, INFO, GUIDE, EPG, DISNEY+, FAV, NETFLIX, / NET TV, YOUTUBE, PRIME VIDEO, / SMART, ROJO, VERDE, AMARILLO, AZUL, MEDIA, SUBTITLE, PLAY/PAUSE, Keys Functions LAYOUT, Code 6511, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWWARRIBAERIOR, ELECTRONICSCOM, .