

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
DEV. LIST
AUTO
TIME SHIFT
ZOOM
FILE LIST
TEXT
V+
V -
CH+
CH -
UP
DOWN
LEFT
RIGHT
ENTER / GROUP
RECALL
INFO
EPG
FAV

RED / FAV. / DAILY
GREEN / DEL. / WEEK.
YELL. / MOV. / P. INFO
BLUE / LOCK / TIMER
LANG.
SUBTITLE
SKIP NEXT
SKIP PREV
TV / RADIO
STOP
REC
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DEV LIST, SOURCE, AUTO, TIME SHIFT, ZOOM, FILE, LIST, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, ENTER, / GROARRIBA, RECALL, BACK, INFO, EPG, FAV, ROJO / FAV / DAILY, ROJO, VERDE / DEL / WEEK, VERDE, YELL / MOV / P INFO, AMARILLO, AZUL / LOCK / TIMER, AZUL, LANG, SUBTITLE, SKIP NEXT, SKIP, PREV, TV / RADIO, TV/DTV, STOP, REC, REW, SHFIT+VERDE, PLAY / PAUSE, FWD, .