

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
AV / SOURCE
REC. LIST
ASPECT
SUBTITLE
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
SLEEP
ATV
i / INFO
TV GUIDE

FAV
HOLD
RED
GREEN
YELLOW
BLUE
DISPLAY
AUDIO
S. MODE
P. MODE
USB
REVEAL
SIZE
SKIP NEXT
SKIP PREV
TV / RADIO
INDEX
STOP
REC
REW
PLAY / PAUSE
FWD

STANDBY, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV / SOURCE, / SOURCE, REC LIST, ASPECT, SUBTITLE, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, ATV, TV/DTV, i / INFO, INFO, TV GUIDE, EPG, FAV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, DISPLAY, AUDIO, S MODE, P MODE, USB, REVEAL, SIZE, SKIP NEXT, SKIP PREV, TV / RADIO, INDEX, STOP, REC, REW, PLAY / PAUSE, FWD, .