

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
PROG. / LOCK
CLEAR / RESET
1/2/3/4/5
6/7/8/9/0
INPUT
CHANNEL 100
MONITOR
X2
SPEED
COUNTER MEMORY
VOLUME+
VOLUME-
CH+
CH-
SLOW+
SLOW-
VIDEO-
VIDEO+
NORMAL
REPEAT
SLEEP
VIDEO
TIME SEARCH

CH. SEARCH
REC END / SEARCH
EJECT
PAUSE / STILL
STOP
RECORD
REW
PLAY
F.FWD
STANDBY
TRACKING+
TRACKING-
RECALL
TIMER
ADD / DELETE
OTR
F. ADV / CS.
SLOW

POWER, MUTE, PROG / LOCK, MENU, CLEAR / RESET, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / AV, CHANNEL 1, 00/, MONITOR, SPEED, COUNTER MEMORY, VOLUME+, VOL+, VOLUME, VOL, CH+, SLOW+, SLOW, ABAJO, VIDEO, IZQUIERDA, VIDEO+, DERECHA, NORMAL, REPEAT, BACK, SLEEP, TV/DTV, TIME SEARCH, INFO, CH SEARCH, EPG, REC END / SEARCH, FAV, EJECT, PAUSE / STILL, STOP, RECORD, ROJO, REW, VERDE, PLAY, AMARILLO, FFWD, AZUL, STANDBY, TRACKING+, TRACKING, RECALL, TIMER, ADD / DELETE, OTR, F ADV / CS, .