

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra en www.mandos.tv



POWER
MUTING
SYSTEM MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
FUNCTION -
FUNCTION+
DISPLAY
VIDEO FORMAT
ANGLE
SUBTITLE / D. TUNING
VOLUME+
VOLUME -
SKIP NEXT / PRESET+
SKIP PREV / PRESET -
UP
DOWN
LEFT
RIGHT
OK
RETURN
SLEEP
TV INPUT
PICTURE NAVI

DYNAMIC BASS
OPEN / CLOSE
PAUSE
STOP
REW / TUNING -
PLAY
FWD / TUNING+
AUDIO
DVD MENU
DVD TOP MENU
MOVIE / MUSIC
[Icon] / DISPLAY
SOUND FIELD+
SOUND FIELD -
[Icon] / REPLAY
[Icon] / ADVANCE
ENTER

Listado de botones del mando:
POWER, MUTING, MUTE, SYSTEM MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION, / SCE, FUNCTION+, DISPLAY, VIDEO FORMAT, ANGLE, SUBTITLE / D TUNING, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, / PRESET+, SKIP PREV / PRESET, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, SLEEP, TV INPUT, TV/DTV, PICTURE NAVI, EPG, DYNAMIC BASS, FAV, OPEN / CLOSE, / NET TV, PAUSE, STOP, / SMART, REW /, TUNING, VERDE, PLAY, AMARILLO, FWD / TUNING+, AZUL, AUDIO, DVD MENU, DVD TOP MENU, MOVIE / MUSIC, / DISPLAY, SOUND FIELD+, SOUND FIELD, VOL, / REPLAY, / ADVANCE, ENTER, .

Mas información sobre este mando en:<https://www.mandos.tv/>
Puede contactar con Mandos.TV de la siguiente manera:
- Teléfono 693057875
- Whatsapp 693057875
- Email soporte@mandos.tv
- Formulario de contacto: Contacto Mandos.TV