


FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
CH. / LIST
PICTURE
PLAYLIST
TV / TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK

ECO. / TFT OFF
INFO
EPG
FAV

HOLD
RED
GREEN
YELLOW
BLUE / SLEEP
AUDIO
CANCEL / GO TO
SOUND
SIZE
SUBTITLE
SKIP NEXT
SKIP PREV
SUBPAGE
REP. / REVEAL
INDEX
PAUSE / TS.
STOP
RECORD
REW
PLAY
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, SOURCE, CH / LIST, PICTURE, PLAYLIST, TV / TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, ECO / TFT OFF, SLEEP, INFO, EPG, FAV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL / SLEEP, AZUL, AUDIO, CANCEL / GO TO, SOUND, SIZE, SUBTITLE, SKIP, NEXT, SKIP, PREV, SUBPAGE, REP / REVEAL, INDEX, PAUSE / TS, STOP, RECORD, REW, PLAY, FWD, .