

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
HOLD
DISPLAY
TIME SHIFT
MIX
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
SLEEP
TV / RADIO
INDEX / REC LIST

EPG
FAV
ASPECT / SIZE
RED
GREEN
YELLOW
BLUE
AUDIO / I/II
P. MODE
S. MODE
/ HOME
REVEAL
/ MOUSE
SUBTITLE
SKIP NEXT
SKIP PREV
STOP
REC
REW
PLAY / PAUSE
FWD

STANDBY, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, HOLD, DISPLAY, TIME SHIFT, MIX, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, TV / RADIO, TV/DTV, INDEX, / REC LIST, INFO, EPG, FAV, ASPECT / SIZE, / NET TV, ROJO, VERDE, AMARILLO, AZUL, AUDIO /, /II, P MODE, S MODE, / HOME, REVEAL, / MOUSE, SUBTITLE, SKIP NEXT, SKIP PREV, STOP, REC, REW, PLAY / PAUSE, FWD, .